

February 17, 2021

Prince George's County Public Schools
Environmental Safety Office
13306 Old Marlboro Pike
Upper Marlboro, MD 20772

Attention: Alex Baylor
alex.baylor@pgcps.org

Subject: Indoor Air Quality Survey
Northwestern High School
7000 Adelphi Road
Hyattsville, MD 20782

Mr. Baylor:

On January 27, 2021, a Soil and Land Use Technology, Inc. (SaLUT) Industrial Hygienist conducted an indoor air quality (IAQ) evaluation at Northwestern High School, a property maintained by Prince George's County Public Schools (PGCPS) located at 7000 Adelphi Road, Hyattsville, MD 20782. The inspection was performed in accordance with PGCPS contract number IFB 022-19.

Methodology

The IAQ evaluation conducted by SaLUT included a visual assessment, IAQ instrumentation screening, and a collection of interior air samples for mold in representative locations throughout the building. Additionally, one building exterior environmental air sample was taken for comparison.

Air-borne fungal spore samples were collected on *Air-O-Cell* cassettes using a Buck BioAire calibrated pump. The air samples were taken between three and five feet from the ground. In tandem with collecting mold samples, real-time readings for carbon dioxide, carbon monoxide, temperature and relative humidity were collected using a Fluke 975 Air Meter in representative areas within the facility.

The fungal spore air samples were delivered to EMSL Analytical, Inc. of Beltsville, Maryland for analysis. Fungal spores and particulates in air samples were analyzed by Optical Microscopy (methods EMSL 05-TP-003 and ASTM D7391). The sample chain-of-custody and laboratory reports are attached.

Observations

The table below summarizes the main observations from the IAQ survey at Northwestern High School, visited on January 27, 2021.

Table 1-Observations

Location	Summary of Observations 01-27-2021
A307 Classroom	2'x4' ceiling tiles and 12" x 12" tile floor; No visual signs of microbial growth; Mild odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
A308 Classroom	2' x 4' ceiling tiles and 12" x 12" tile floor; No visual signs of microbial growth; Mild odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
A324 Classroom	2'x4' ceiling tiles and 12"x12" tile floor; No visual signs of microbial growth, and no odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
B213 Classroom	2'x4' ceiling tiles; No visual signs of microbial growth; Mild odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
B-Wing Hallway	2'x4' ceiling tiles and 12"x12" tile floor; No visual signs of microbial growth, and no odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
Work room C228	2'x2' ceiling tiles and 12" x 12" tile floor; No visual signs of microbial growth; Mild odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
J127 Locker room	2'x4' ceiling tiles and no floor tiles; No visual signs of microbial growth, and no odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
Gymnasium	Wooden floor and no ceiling; No visual signs of microbial growth, and no odor; No visible dust on floor/other furniture surfaces;

Location	Summary of Observations 01-27-2021
	No visible dust around ventilator; Central AC.
Skywalk Main Hallway	2'x4' ceiling tiles and 12"x12" tile floor; No visual signs of microbial growth, and no odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.
Kitchen/Cafeteria	No floor tiles in the kitchen; 2'x 2' ceiling tiles and 12"x12" tile floor; No visual signs of microbial growth, and no odor; No visible dust on floor/other furniture surfaces; No visible dust around ventilator; Central AC.

Measurements of Indoor Environmental Quality Parameters

Table 2 depicts a summary of average measurements of comfort.

Temperature

The American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE) have published recommendations for year round acceptable temperatures in Standard 55-2010 *Thermal Environmental Conditions for Human Occupancy*. The winter comfort range is 20 to 24°C (68 to 75°F) and 23 to 26°C (73 to 79°F) is the summer comfort range. The temperature readings were within the ASHRAE recommended ranges in the representative spaces.

Relative Humidity (RH)

RH is a key factor for mold growth. Mold has the potential of growing on suitable surfaces with humidity levels above 60%. ASHRAE Standard 62.1-2010 *Ventilation for Acceptable Indoor Air Quality* recommends a maximum indoor RH of 65% to preclude the likelihood of condensation on cool surfaces encouraging mold growth. The RH readings were within the ASHRAE recommended ranges in the representative areas.

Carbon Dioxide (CO₂)

Under conditions of maximum occupancy, ASHRAE Standard 62.1-2010, Appendix C, infers that the acceptable CO₂ upper limit is the prevailing outdoor CO₂ concentration plus 700 parts per million (ppm). On the day of the space evaluation, the outdoor (building exterior) CO₂ concentration was approximately 414 ppm therefore indoor concentrations should not exceed approximately 1,114 ppm (700 + 414). The maximum average interior CO₂ concentration detected was 598 ppm in Work Room C228, a range within the ASHRAE recommendations, per Table 2 below.

Carbon Monoxide (CO)

CO is a colorless and odorless gas that is produced by the incomplete combustion of carbon containing fuels. Oil, gasoline, diesel fuels, wood, coke, and coal are major sources of CO. All registered CO concentrations were below the EPA National Ambient Air Quality Standard (NAAQS) of 9 ppm, per Table 2 below.

**Table 2: Northwestern High School - Instrumental Screening Levels
January 27, 2021 (9:30 AM-11:30 AM)**

Sample Location	Temp °F	RH%	CO ppm	CO ₂ ppm
Standards	ASHRAE 68 to 75°F*	ASHRAE <65%	NAAQS 9	ASHRAE 1,114
A307 Classroom	74.3	23.3	0	526
A308 Classroom	74.2	22.4	0	494
A324 Classroom	75.0	22.4	0	478
B213 Classroom	74.3	22.1	0	478
B-Wing Hallway	74.3	22.1	0	494
Work Room C228	75.0	23.1	0	598
J127 Locker Room	72.5	24.6	0	476
Gymnasium	71.6	24.3	0	467
Skywalk Main Hallway	68.9	26.3	0	463
Kitchen/Cafeteria	69.8	26.0	0	470
Outside Exterior EV Sample	44.6	45.9	0	414

PM - Particulate Matter size

°F - Degrees Fahrenheit

CO - Carbon Monoxide

ppm - parts per million

µg/m³ - micrograms per cubic meter

RH% - % Relative Humidity

CO₂ - Carbon Dioxide

* - Winter Comfort Range

Mold-in-Air Samples

There are no definitive regulations or standardized guidelines for addressing airborne mold in an indoor setting. If building systems (ventilation, envelope) are functioning properly, the indoor population profile should mimic what is encountered outdoors and the concentrations should be below the outdoor (building exterior) environmental sample levels.

Table 3: Summarizes airborne mold spore sampling results and locations. On January 27, 2021, total mold counts in representative samples (spore count/m³ of air) in all the areas inspected were lower than the outdoor concentrations. Laboratory analysis follows this report (see attachment).

**Table 3: Northwestern High School
Measurements of Mold-in-Air Samples
January 27, 2021 (9:30 AM-11:30 AM)**

Spore Types	A307 Classroom	A308 Classroom	A324 Classroom	B213 Classroom	B-Wing Hallway	Work Room C228
<i>Alternaria (Ulocladium)</i>	-	-	-	-	-	-
<i>Ascospores</i>	-	-	-	-	-	-
<i>Aspergillus/Penicillium</i>	-	-	-	-	-	-
<i>Basidiospores</i>	-	-	-	-	-	-
<i>Bipolaris++</i>	-	-	-	-	-	-
<i>Chaetomium</i>	-	-	-	-	-	-
<i>Cladosporium</i>	10*	-	-	-	10*	-
<i>Curvularia</i>	-	-	-	-	-	-
<i>Epicoccum</i>	-	-	-	-	-	-
<i>Fusarium</i>	-	-	-	-	-	-
<i>Ganoderma</i>	-	-	-	-	-	-
<i>Myxomycetes++</i>	-	-	-	-	-	-
<i>Pithomyces++</i>	-	-	-	-	-	-
<i>Rust</i>	-	-	-	-	-	-
<i>Scopulariopsis/Microascus</i>	-	-	-	-	-	-
<i>Stachybotrys/Memnoniella</i>	-	-	-	-	-	-
<i>Unidentifiable Spores</i>	-	-	-	-	-	-
<i>Zygomycetes</i>	-	-	-	-	-	-
<i>Nigrospora</i>	-	-	-	-	-	-
<i>Hyphal Fragment</i>	10*	-	-	-	-	-
<i>Insect Fragment</i>	10*	-	-	-	-	-
<i>Pollen</i>	-	-	-	-	-	-
Total Fungi	30	None Detect	None Detect	None Detect	10*	None Detect

* Spore Counts per cubic meter of air (Counts/m³).

++Includes other spores with similar morphology.

**Table 3: Northwestern High School
Measurements of Mold-in-Air Samples continued
January 27, 2021 (9:30 AM-11:30 AM)**

Spore Types	J127 Locker Room	Gymnasium	Skywalk Main Hallway	Kitchen/Cafeteria	Outside Exterior EV Sample	Field Sample
<i>Alternaria (Ulocladium)</i>	-	-	-	-	40	-
<i>Ascospores</i>	-	-	-	-	-	-
<i>Aspergillus/Penicillium</i>	-	-	-	-	440	-
<i>Basidiospores</i>	90	-	-	-	-	-
<i>Bipolaris++</i>	-	-	-	-	-	-
<i>Chaetomium</i>	-	-	-	-	-	-
<i>Cladosporium</i>	-	-	-	-	-	-
<i>Curoularia</i>	-	-	-	-	-	-
<i>Epicoccum</i>	-	-	-	-	-	-
<i>Fusarium</i>	-	-	-	-	-	-
<i>Ganoderma</i>	-	-	-	-	-	-
<i>Myxomycetes++</i>	-	-	-	-	-	-
<i>Pithomyces++</i>	-	-	-	-	-	-
<i>Rust</i>	-	-	-	-	-	-
<i>Scopulariopsis/Microascus</i>	-	-	-	-	-	-
<i>Stachybotrys/Memnoniella</i>	-	-	-	-	-	-
<i>Unidentifiable Spores</i>	-	-	-	-	-	-
<i>Zygomycetes</i>	-	-	-	-	-	-
<i>Nigrospora</i>	-	-	-	-	-	-
<i>Hyphal Fragment</i>	-	-	-	-	10*	-
<i>Insect Fragment</i>	-	-	-	-	-	-
<i>Pollen</i>	-	-	-	-	-	-
Total Fungi	90	None Detect	None Detect	None Detect	490	None Detect

*Spore Counts per cubic meter of air (Counts/m³).

++Includes other spores with similar morphology.

Findings and Conclusions

The comfort parameters (i.e., temperature, RH, CO₂, and CO levels) in the representative areas conform to ASHRAE and/or NAAQS guidelines. On January 27, 2021 total mold counts in representative area samples (spore count/m³ of air) in all the areas inspected were lower than the outdoor concentrations.

Thank you for the opportunity to provide industrial hygiene services for PGCPS. If you have any questions, please contact me at 301.595.3783.

Sincerely,



Chaminda Jayatilake, PE, CIH, CSP, CHMM
Certified Industrial Hygienist
Soil and Land Use Technology Inc. (SaLUT)

Attachment

Attachment - Mold Spore Sample Analytical Results and Chain-of-Custody Forms

Attachment

Mold Spore Sample Analytical Results and Chain-of-Custody Forms



EMSL Analytical, Inc.

10768 Baltimore Avenue Beltsville, MD 20705

Tel/Fax: (301) 937-5700 / (301) 937-5701

<http://www.EMSL.com> / beltsvillelab@emsl.com

EMSL Order: 192100818

Customer ID: SALU50

Customer PO:

Project ID:

Attention: Indika Jayatilake

SaLUT

1818 New York Avenue, NE

Suite 231

Washington, DC 20002

Project: PGPCS IAQ Reports 19-035 North Western High School

Phone: (301) 595-3783

Fax: (301) 595-3787

Collected Date: 01/27/2021

Received Date: 01/28/2021 08:30 AM

Analyzed Date: 01/29/2021

Test Report: Air-O-Cell™ Analysis of Fungal Spores & Particulates by Optical Microscopy (Methods MICRO-SOP-201, ASTM D7391)

Lab Sample Number:	192100818-0001			192100818-0002			192100818-0003		
Client Sample ID:	3162 6152			3162 6156			3162 6131		
Volume (L):	75			75			75		
Sample Location:	Work room C228			A307 Classroom			A308 Classroom		
Spore Types	Raw Count	Count/M ³	% of Total	Raw Count	Count/M ³	% of Total	Raw Count	Count/M ³	% of Total
Alternaria (Ulocladium)	-	-	-	-	-	-	-	-	-
Ascospores	-	-	-	-	-	-	-	-	-
Aspergillus/Penicillium	-	-	-	-	-	-	-	-	-
Basidiospores	-	-	-	-	-	-	-	-	-
Bipolaris++	-	-	-	-	-	-	-	-	-
Chaetomium	-	-	-	-	-	-	-	-	-
Cladosporium	-	-	-	1*	10*	100	-	-	-
Curvularia	-	-	-	-	-	-	-	-	-
Epicoccum	-	-	-	-	-	-	-	-	-
Fusarium	-	-	-	-	-	-	-	-	-
Ganoderma	-	-	-	-	-	-	-	-	-
Myxomycetes++	-	-	-	-	-	-	-	-	-
Pithomyces++	-	-	-	-	-	-	-	-	-
Rust	-	-	-	-	-	-	-	-	-
Scopulariopsis/Microascus	-	-	-	-	-	-	-	-	-
Stachybotrys/Memnoniella	-	-	-	-	-	-	-	-	-
Unidentifiable Spores	-	-	-	-	-	-	-	-	-
Zygomycetes	-	-	-	-	-	-	-	-	-
Total Fungi	-	None Detect	-	1	10	100	-	None Detect	-
Hyphal Fragment	-	-	-	1*	10*	-	-	-	-
Insect Fragment	-	-	-	1*	10*	-	-	-	-
Pollen	-	-	-	-	-	-	-	-	-
Analyt. Sensitivity 600x	-	44	-	-	44	-	-	44	-
Analyt. Sensitivity 300x	-	13*	-	-	13*	-	-	13*	-
Skin Fragments (1-4)	-	2	-	-	2	-	-	1	-
Fibrous Particulate (1-4)	-	1	-	-	1	-	-	1	-
Background (1-5)	-	1	-	-	1	-	-	1	-

++ Includes other spores with similar morphology; see EMSL's fungal glossary for each specific category.

Abubakar Barry, Microbiology Laboratory Manager
or other Approved Signatory

EMSL maintains liability limited to cost of analysis. Interpretation and use of test results are the responsibility of the client. This report relates only to the samples reported above, and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. The report reflects the samples as received. Results are generated from the field sampling data (sampling volumes and areas, locations, etc.) provided by the client on the Chain of Custody. Samples are within quality control criteria and met method specifications unless otherwise noted. High levels of background particulate can obscure spores and other particulates, leading to underestimation. Background levels of 5 indicate an overloading of background particulates, prohibiting accurate detection and quantification. Present = Spores detected on overloaded samples. Results are not blank corrected unless otherwise noted. The detection limit is equal to one fungal spore, structure, pollen, fiber particle or insect fragment. "*" Denotes particles found at 300X. "-" Denotes not detected. Due to method stopping rules, raw counts in excess of 100 are extrapolated based on the percentage analyzed.

Samples analyzed by EMSL Analytical, Inc. Beltsville, MD AIHA-LAP, LLC-EMLAP Accredited #102891

Initial report from: 02/01/2021 11:17 AM

For information on the fungi listed in this report, please visit the Resources section at www.emsl.com



EMSL Analytical, Inc.

10768 Baltimore Avenue Beltsville, MD 20705

Tel/Fax: (301) 937-5700 / (301) 937-5701

<http://www.EMSL.com> / beltsvillelab@emsl.com

EMSL Order: 192100818

Customer ID: SALU50

Customer PO:

Project ID:

Attention: Indika Jayatilake

SaLUT

1818 New York Avenue, NE

Suite 231

Washington, DC 20002

Project: PGPCS IAQ Reports 19-035 North Western High School

Phone: (301) 595-3783

Fax: (301) 595-3787

Collected Date: 01/27/2021

Received Date: 01/28/2021 08:30 AM

Analyzed Date: 01/29/2021

Test Report: Air-O-Cell™ Analysis of Fungal Spores & Particulates by Optical Microscopy (Methods MICRO-SOP-201, ASTM D7391)

Lab Sample Number:	192100818-0004			192100818-0005			192100818-0006		
Client Sample ID:	3162 6157			3162 6148			3162 5337		
Volume (L):	75			75			75		
Sample Location:	A324 Classroom			B213 Classroom			B-Wing Hallway		
Spore Types	Raw Count	Count/M ³	% of Total	Raw Count	Count/M ³	% of Total	Raw Count	Count/M ³	% of Total
Alternaria (Ulocladium)	-	-	-	-	-	-	-	-	-
Ascospores	-	-	-	-	-	-	-	-	-
Aspergillus/Penicillium	-	-	-	-	-	-	-	-	-
Basidiospores	-	-	-	-	-	-	-	-	-
Bipolaris++	-	-	-	-	-	-	-	-	-
Chaetomium	-	-	-	-	-	-	-	-	-
Cladosporium	-	-	-	-	-	-	1*	10*	100
Curvularia	-	-	-	-	-	-	-	-	-
Epicoccum	-	-	-	-	-	-	-	-	-
Fusarium	-	-	-	-	-	-	-	-	-
Ganoderma	-	-	-	-	-	-	-	-	-
Myxomycetes++	-	-	-	-	-	-	-	-	-
Pithomyces++	-	-	-	-	-	-	-	-	-
Rust	-	-	-	-	-	-	-	-	-
Scopulariopsis/Microascus	-	-	-	-	-	-	-	-	-
Stachybotrys/Memnoniella	-	-	-	-	-	-	-	-	-
Unidentifiable Spores	-	-	-	-	-	-	-	-	-
Zygomycetes	-	-	-	-	-	-	-	-	-
Total Fungi	-	None Detect	-	-	None Detect	-	1	10	100
Hyphal Fragment	-	-	-	-	-	-	-	-	-
Insect Fragment	-	-	-	-	-	-	-	-	-
Pollen	-	-	-	-	-	-	-	-	-
Analyt. Sensitivity 600x	-	44	-	-	44	-	-	44	-
Analyt. Sensitivity 300x	-	13*	-	-	13*	-	-	13*	-
Skin Fragments (1-4)	-	1	-	-	2	-	-	1	-
Fibrous Particulate (1-4)	-	1	-	-	1	-	-	1	-
Background (1-5)	-	1	-	-	1	-	-	1	-

++ Includes other spores with similar morphology; see EMSL's fungal glossary for each specific category.

Abubakar Barry, Microbiology Laboratory Manager
or other Approved Signatory

EMSL maintains liability limited to cost of analysis. Interpretation and use of test results are the responsibility of the client. This report relates only to the samples reported above, and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. The report reflects the samples as received. Results are generated from the field sampling data (sampling volumes and areas, locations, etc.) provided by the client on the Chain of Custody. Samples are within quality control criteria and met method specifications unless otherwise noted. High levels of background particulate can obscure spores and other particulates, leading to underestimation. Background levels of 5 indicate an overloading of background particulates, prohibiting accurate detection and quantification. Present = Spores detected on overloaded samples. Results are not blank corrected unless otherwise noted. The detection limit is equal to one fungal spore, structure, pollen, fiber particle or insect fragment. "*" Denotes particles found at 300X. "-" Denotes not detected. Due to method stopping rules, raw counts in excess of 100 are extrapolated based on the percentage analyzed.

Samples analyzed by EMSL Analytical, Inc. Beltsville, MD AIHA-LAP, LLC-EMLAP Accredited #102891

Initial report from: 02/01/2021 11:17 AM

For information on the fungi listed in this report, please visit the Resources section at www.emsl.com



EMSL Analytical, Inc.

10768 Baltimore Avenue Beltsville, MD 20705

Tel/Fax: (301) 937-5700 / (301) 937-5701

<http://www.EMSL.com> / beltsvillelab@emsl.com

EMSL Order: 192100818
Customer ID: SALU50
Customer PO:
Project ID:

Attention: Indika Jayatilake
 SaLUT
 1818 New York Avenue, NE
 Suite 231
 Washington, DC 20002

Phone: (301) 595-3783
Fax: (301) 595-3787
Collected Date: 01/27/2021
Received Date: 01/28/2021 08:30 AM
Analyzed Date: 01/29/2021

Project: PGPCS IAQ Reports 19-035 North Western High School

Test Report: Air-O-Cell™ Analysis of Fungal Spores & Particulates by Optical Microscopy (Methods MICRO-SOP-201, ASTM D7391)

Lab Sample Number: Client Sample ID: Volume (L): Sample Location:	192100818-0007 3162 5319 75 J127 Locker room			192100818-0008 3162 5383 75 Gymnasium			192100818-0009 3162 5384 75 Skywalk Main Hallway			
	Spore Types	Raw Count	Count/M ³	% of Total	Raw Count	Count/M ³	% of Total	Raw Count	Count/M ³	% of Total
Alternaria (Ulocladium)	-	-	-	-	-	-	-	-	-	-
Ascospores	-	-	-	-	-	-	-	-	-	-
Aspergillus/Penicillium	-	-	-	-	-	-	-	-	-	-
Basidiospores	2	90	100	-	-	-	-	-	-	-
Bipolaris++	-	-	-	-	-	-	-	-	-	-
Chaetomium	-	-	-	-	-	-	-	-	-	-
Cladosporium	-	-	-	-	-	-	-	-	-	-
Curvularia	-	-	-	-	-	-	-	-	-	-
Epicoccum	-	-	-	-	-	-	-	-	-	-
Fusarium	-	-	-	-	-	-	-	-	-	-
Ganoderma	-	-	-	-	-	-	-	-	-	-
Myxomycetes++	-	-	-	-	-	-	-	-	-	-
Pithomyces++	-	-	-	-	-	-	-	-	-	-
Rust	-	-	-	-	-	-	-	-	-	-
Scopulariopsis/Microascus	-	-	-	-	-	-	-	-	-	-
Stachybotrys/Memnoniella	-	-	-	-	-	-	-	-	-	-
Unidentifiable Spores	-	-	-	-	-	-	-	-	-	-
Zygomycetes	-	-	-	-	-	-	-	-	-	-
Total Fungi	2	90	100	-	None Detect	-	-	None Detect	-	-
Hyphal Fragment	-	-	-	-	-	-	-	-	-	-
Insect Fragment	-	-	-	-	-	-	-	-	-	-
Pollen	-	-	-	-	-	-	-	-	-	-
Analyt. Sensitivity 600x	-	44	-	-	44	-	-	44	-	-
Analyt. Sensitivity 300x	-	13*	-	-	13*	-	-	13*	-	-
Skin Fragments (1-4)	-	2	-	-	1	-	-	1	-	-
Fibrous Particulate (1-4)	-	1	-	-	1	-	-	1	-	-
Background (1-5)	-	1	-	-	1	-	-	1	-	-

++ Includes other spores with similar morphology; see EMSL's fungal glossary for each specific category.

**Abubakar Barry, Microbiology Laboratory Manager
 or other Approved Signatory**

EMSL maintains liability limited to cost of analysis. Interpretation and use of test results are the responsibility of the client. This report relates only to the samples reported above, and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. The report reflects the samples as received. Results are generated from the field sampling data (sampling volumes and areas, locations, etc.) provided by the client on the Chain of Custody. Samples are within quality control criteria and met method specifications unless otherwise noted. High levels of background particulate can obscure spores and other particulates, leading to underestimation. Background levels of 5 indicate an overloading of background particulates, prohibiting accurate detection and quantification. Present = Spores detected on overloaded samples. Results are not blank corrected unless otherwise noted. The detection limit is equal to one fungal spore, structure, pollen, fiber particle or insect fragment. "" Denotes particles found at 300X. "-" Denotes not detected. Due to method stopping rules, raw counts in excess of 100 are extrapolated based on the percentage analyzed.

Samples analyzed by EMSL Analytical, Inc. Beltsville, MD AIHA-LAP, LLC-EMLAP Accredited #102891

Initial report from: 02/01/2021 11:17 AM

For information on the fungi listed in this report, please visit the Resources section at www.emsl.com



EMSL Analytical, Inc.

10768 Baltimore Avenue Beltsville, MD 20705

Tel/Fax: (301) 937-5700 / (301) 937-5701

<http://www.EMSL.com> / beltsvillelab@emsl.com

EMSL Order: 192100818
Customer ID: SALU50
Customer PO:
Project ID:

Attention: Indika Jayatilake
 SaLUT
 1818 New York Avenue, NE
 Suite 231
 Washington, DC 20002

Phone: (301) 595-3783
Fax: (301) 595-3787
Collected Date: 01/27/2021
Received Date: 01/28/2021 08:30 AM
Analyzed Date: 01/29/2021

Project: PGPCS IAQ Reports 19-035 North Western High School

Test Report: Air-O-Cell™ Analysis of Fungal Spores & Particulates by Optical Microscopy (Methods MICRO-SOP-201, ASTM D7391)

Lab Sample Number: Client Sample ID: Volume (L): Sample Location:	192100818-0010 3162 5384 75 Kitchen/ Cafeteria			192100818-0011 3162 5362 75 Outside sample			192100818-0012 3162 5309 Field Blank			
	Spore Types	Raw Count	Count/M³	% of Total	Raw Count	Count/M³	% of Total	Raw Count	Count/M³	% of Total
Alternaria (Ulocladium)	-	-	-	-	-	-	-	-	-	-
Ascospores	-	-	-	1	40	8.3	-	-	-	-
Aspergillus/Penicillium	-	-	-	-	-	-	-	-	-	-
Basidiospores	-	-	-	10	440	91.7	-	-	-	-
Bipolaris++	-	-	-	-	-	-	-	-	-	-
Chaetomium	-	-	-	-	-	-	-	-	-	-
Cladosporium	-	-	-	-	-	-	-	-	-	-
Curvularia	-	-	-	-	-	-	-	-	-	-
Epicoccum	-	-	-	-	-	-	-	-	-	-
Fusarium	-	-	-	-	-	-	-	-	-	-
Ganoderma	-	-	-	-	-	-	-	-	-	-
Myxomycetes++	-	-	-	-	-	-	-	-	-	-
Pithomyces++	-	-	-	-	-	-	-	-	-	-
Rust	-	-	-	-	-	-	-	-	-	-
Scopulariopsis/Microascus	-	-	-	-	-	-	-	-	-	-
Stachybotrys/Memnoniella	-	-	-	-	-	-	-	-	-	-
Unidentifiable Spores	-	-	-	-	-	-	-	-	-	-
Zygomycetes	-	-	-	-	-	-	-	-	-	-
Total Fungi	-	No Trace	-	11	480	100	-	No Trace	-	-
Hyphal Fragment	-	-	-	1*	10*	-	-	-	-	-
Insect Fragment	-	-	-	-	-	-	-	-	-	-
Pollen	-	-	-	-	-	-	-	-	-	-
Analyt. Sensitivity 600x	-	44	-	-	44	-	-	0	-	-
Analyt. Sensitivity 300x	-	13*	-	-	13*	-	-	0*	-	-
Skin Fragments (1-4)	-	-	-	-	1	-	-	-	-	-
Fibrous Particulate (1-4)	-	-	-	-	1	-	-	-	-	-
Background (1-5)	-	-	-	-	1	-	-	-	-	-

++ Includes other spores with similar morphology; see EMSL's fungal glossary for each specific category.

**Abubakar Barry, Microbiology Laboratory Manager
 or other Approved Signatory**

EMSL maintains liability limited to cost of analysis. Interpretation and use of test results are the responsibility of the client. This report relates only to the samples reported above, and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. The report reflects the samples as received. Results are generated from the field sampling data (sampling volumes and areas, locations, etc.) provided by the client on the Chain of Custody. Samples are within quality control criteria and met method specifications unless otherwise noted. High levels of background particulate can obscure spores and other particulates, leading to underestimation. Background levels of 5 indicate an overloading of background particulates, prohibiting accurate detection and quantification. Present = Spores detected on overloaded samples. Results are not blank corrected unless otherwise noted. The detection limit is equal to one fungal spore, structure, pollen, fiber particle or insect fragment. "*" Denotes particles found at 300X. "-" Denotes not detected. Due to method stopping rules, raw counts in excess of 100 are extrapolated based on the percentage analyzed.

Samples analyzed by EMSL Analytical, Inc. Beltsville, MD AIHA-LAP, LLC-EMLAP Accredited #102891

Initial report from: 02/01/2021 11:17 AM

For information on the fungi listed in this report, please visit the Resources section at www.emsl.com



EMSL ANALYTICAL, INC.
LABORATORY PRODUCTS TRAINING

Microbiology Chain of Custody

EMSL Order Number (Lab Use Only):

192100818

EMSL Analytical, Inc.
10768 Baltimore Avenue

Beltsville, MD 20705

PHONE: (301) 937-5700

FAX: (301) 937-5701

Company Name: SaLUT		EMSL-Bill to: <input checked="" type="checkbox"/> Same <input type="checkbox"/> Different If 'Bill To' is different, note instructions in Comments <i>Third Party Billing requires written authorization from third party.</i>					
Street: 1818 New York Avenue, NE Suite 231							
City: Washington	State/Province: DC	Zip/Postal Code: 20002	Country: US				
Report To (Name): Indika Jayatilake		Telephone #: 301-595-3783					
Email Address: ijayatilake@salutinc.com		Fax #: 301-595-3787			Purchase Order:		
Project Name/Number: PGPCS IAQ Reports 19-035 <i>North Western High School</i>		Please Provide Results: <input type="checkbox"/> Fax <input checked="" type="checkbox"/> Email					
U.S. State Samples Taken: MD		Project Zip Code:		Connecticut Samples: <input type="checkbox"/> Commercial <input type="checkbox"/> Residential			
Sterile, Sodium Thiosulfate Preserved Bottle Used: <input type="checkbox"/> Biocide Used in Source (specify): <input type="checkbox"/>							
Public Water Supply Samples: <input type="checkbox"/> Note: All results may automatically be reported to DOH if required by state.							
Turnaround Time (TAT) Options - Please Check							
<input type="checkbox"/> 3 Hour	<input type="checkbox"/> 6 Hour	<input type="checkbox"/> 24 Hour	<input type="checkbox"/> 48 Hour	<input checked="" type="checkbox"/> 72 Hour	<input type="checkbox"/> 96 Hour	<input type="checkbox"/> 1 Week <input type="checkbox"/> 2 Week	
Microbiology Test Codes							
M001 Air-O-Cell	M174 MoldSnap	M012 <i>Pseudomonas aeruginosa</i> (PIA***)	M115 Sewage Screen - Water (PIA***)				
M030 Micro 5	M032 Allergenco-D	M024 <i>Pseudomonas aeruginosa</i> (MFT*)	M116 Sewage Screen - Water (MPN**)				
M041 Fungal Direct Examination		M015 Heterotrophic Plate Count	M117 Sewage Screen - Swab (PIA***)				
M169 Pollen ID & Enumeration		M017 Total Coliform & <i>E. coli</i> (Colilert P/A***)	M013 Sewage Screen - Swab (MFT*)				
M280 Dust Characterization Level-1		M018 Total Coliform & <i>E. coli</i> (MFT*)	M133 <i>Methicillin-resistant Staph. aureus</i> (MRSA)				
M281 Dust Characterization Level-2		M114 Total Coliform & <i>E. coli</i> Enumeration (Colilert MPN**)	M031 Rapid-growing non-TB <i>Mycobacteria</i> Detection & Enumeration				
M005 Viable Fungi- Air Samples (Genus ID & Count)		M019 Fecal Coliform (MFT*)	M014 Endotoxin Analysis				
M006 Viable Fungi- Air Samples (Includes <i>Penicillium</i> , <i>Aspergillus</i> , <i>Cladosporium</i> , <i>Stachybotrys</i> Species ID & Count)		M020 Fecal <i>Streptococcus</i> (MFT*)	M044 Group Allergen (Cat, Dog, Cockroach, Dust Mite)				
M007 Culturable fungi - Surface Samples (Genus ID & Count)		M029 <i>Enterococci</i> (MFT*)	Other See Analytical Price Guide				
M008 Culturable fungi - Surface Samples (Includes <i>Penicillium</i> , <i>Aspergillus</i> , <i>Cladosporium</i> , <i>Stachybotrys</i> Species ID & Count)		M129 <i>Enterococci</i> (Enterolert P/A***)	Legionella Analysis Please use EMSL Legionella COC				
M009 Bacteria Culture Gram Stain & Count		M180 Real Time qPCR-ERMI 36 Panel					
M010 Bacteria Count & ID - 3 Most Prominent		M025 Sewage Screen -Water (MFT*)					
M011 Bacteria Count & ID - 5 Most Prominent							
*MFT= Membrane Filtration Technique **MPN= Most Probable Number ***P/A= Presence/Absence							
Name of Sampler: <i>Rahul Ekanayake</i>			Signature of Sampler:				
Sample #	Sample Location/Description	Sample Type	Potable/ NonPotable (Only for Waters)	Test Code	Volume/ Area	Date/Time Collected	Temperature (°C) (Lab Use Only)
Example A1	Kitchen Sink/Tap	Water	<input checked="" type="checkbox"/> P <input type="checkbox"/> NP	M017	100 mL	9/1/13 4:00 PM	
3162 6152	Workroom C228	Air	<input type="checkbox"/> P <input type="checkbox"/> NP	M001	75L	01/27/21 2:45 P.M	
3162 6156	A307 Classroom	Air	<input type="checkbox"/> P <input type="checkbox"/> NP	M001	75L	01/27/21 3:00 P.M	
3162 6131	A308 Classroom	Air	<input type="checkbox"/> P <input type="checkbox"/> NP	M001	75L	01/27/21 3:10 P.M	
3162 6157	A324 Classroom	Air	<input type="checkbox"/> P <input type="checkbox"/> NP	M001	75L	01/27/21 3:17 P.M	
3162 6148	B213 Classroom	Air	<input type="checkbox"/> P <input type="checkbox"/> NP	M001	75L	01/27/21 3:22 P.M	
Client Sample # (s): - 12		Total # of Samples: 12		Samples Received Chilled? Yes/No (Lab Use Only)			
Relinquished (Client): <i>Rahul Ekanayake</i>			Date: 01/27/21		Time: 6:00 P.M		
Received (Lab):			Date:		Time:		
Comments/Special Instructions:							

EMSL Analytical, Inc.'s Laboratory Terms and Conditions are incorporated into this chain of custody by reference in their entirety. Submission of samples to EMSL Analytical, Inc. constitutes acceptance and acknowledgment of all terms and conditions by Customer.

RECEIVED
 EMSL ANALYTICAL, INC.
 BELTSVILLE, MD
 2021 JAN 28 A 7:23

